



Material List	
Concrete	1000
Sand	500
Gravel	200
Rebar	10
Formwork	5

Dimensions	
Length	10m
Width	5m
Height	0.2m

Notes	
1.	Ensure all materials are of high quality.
2.	Check dimensions before pouring concrete.
3.	Use proper curing techniques.

Schedule	
Excavation	1-2 days
Formwork	2-3 days
Pouring	1 day
Curing	7 days

Safety	
Wear PPE	Always
Use Safety Harness	When working at height
First Aid Kit	Available on site

Quality Control	
Check Rebar Placement	Before pouring
Test Concrete Strength	After 28 days
Inspect Formwork	Before use

Site Information	
Site Name	Project X
Location	123 Main St
Date	2023-10-27

Approval	
Prepared by	John Doe
Reviewed by	Jane Smith
Approved by	Bob Johnson

References	
Code	ACI 308
Standard	ASTM C1190
Manual	Concrete Formwork Handbook

